


ST 1800



DISPLAY OPTIONS*

1. Product Height
2. Gross Volume
3. Ullage
4. Water Height
5. Product Temperature
6. Report History
7. Product Dispensed
8. System Status
9. Leak Detection

*Press "E" to get to
"SELECT DISPLAY"

CONSOLE

DISPLAY

LINE LEAK TEST	08AUG94 12:08:32
LINE 01	
LINE LEAK START TIME	02AUG94 10:56:01
LINE LEAK END TIME	02AUG94 12:08:22
ENDING PRESSURE	9.3 PSI
T: 3599/0008	A01
AIR COUNTER	0
COMPLETE PRECISION TEST	
END OF REPORT	

RED JACKET LEAK DETECTION SYSTEMS
VERSION RJ1-12 020CT95

SHORT STOP
7647 LEAVENWORTH
KANSAS CITY, KS.
913-788-3091

LEAK TEST	
29MAV97	01:27:32
TANK 2 UNLEADED PREM	-0.038 GAL/H FAIL
ALARM LEAK RATE	0.050 GAL/H
PROBABILITY OF DETECTION	99.9%
PRODUCT HEIGHT	39.54 INCHES
PRODUCT VOLUME	4009.7 GALLONS
LEAK DET START TIME	28MAV97 22:15:59
LEAK DET END TIME	29MAV97 01:27:32
LEAK DET PERIOD	03 HRS 11 MINS
LEAK DET START WATER	0.00 INCHES
LEAK DET END WATER	0.00 INCHES
LAST DELIVERY	26MAV97 16:34:46
LEAK TEST NO	1935
END OF REPORT	

1. View Display Options (at SELECT DISPLAY)

- a. Press desired **display option** keypad #
- b. Press ↑ or ↓ key to view remaining tanks

2. View History Reports (including leak test)

- a. Press **6**
- b. Press → to scroll to desired report
- c. Press ↑ or ↓ key to scroll to "reserved report number"
- d. Press → or ← to view info

3. Print Inventory Report

(green 'OL' indicator light must be on)

- a. Press **P** key for all tanks
 - i. **For only one feature**, press desired option keypad #
 - ii. Press **P**

4. Print History Reports

(green 'OL' indicator light must be on)

- a. Press **6**
- b. Press → to scroll to desired report
- c. Press ↑ or ↓ key to scroll to "reserved report number"
- d. Press **P** to print report